


# 1. Bluetooth Connection and Printing



1. Scan Bluetooth -> Printer -> Selected Cell Printer
2. And tip the connect success or fail
3. You can print text \ barcode \ qrcode \ picture

## 2. Delegate implementation

IHRBLEManagerDelegate in IHRBlueListVC class

```
- (void) viewDidLoad {
    [super viewDidLoad];

    // delegate
    [IHRBLEManager sharedInstance].delegate = self;
}

// delegate
- (void) IHRbleUpdatePeripheralList: (NSArray *) peripherals RSSIList:(NSArray *) rssiList {
    //

});
}

- (void) IHRbleConnectPeripheral: (CBPeripheral *) peripheral {
    //

}

- (void) IHRbleFailToConnectPeripheral: (CBPeripheral *) peripheral error: (NSError *) error {
    //

}
...
```